

Work Order ID 61098

August 6, 2010 9:24:06 AM



Page 1

Item ID: D212-664-101

Accept



Setup Start



Revision ID:

Stop



Item Name: Crosstube Fwd

Start Date: 8/06/10 Start Qty: 1.00



Cust Item ID:

Required Date: 8/10/10 Req'd Qty: 1.00



Customer:

Reference: RA110015 - RETURN

Approvals: Process Plan:

Date:

Tooling:

Date:

Run Start



QC:

Date:

SPC (Y/N):

Date:

Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

D212-664-141

Rev D

100

0.00



DOCUMENT CONTROL

DC

Memo

0.00

Document Control

Photocopy bluefile and create labels as per PPP D212-664-101 CHG003

Siobylko

MF 10-8-10

250

QC4- 100% Inspect kits for completeness

0.00



QC

Memo

0.00

Quality Control

Inspect tube and kit from RA110015

Siobylko

(H)

260

Packaging

0.00



Packaging

Memo

0.00

Packaging

RE-PACKAGE PER PPP USING NEW B/N
NEW LABELS AND PAPERWOK REQ'D

Rev

W. H. H. H.

Siobylko

Work Order ID 61098

Page 2

August 6, 2010 9:24:06 AM

Item ID: D212-664-101

Accept



Setup Start



Revision ID:

Stop



Item Name: Crosstube Fwd

Start Date: 8/06/10 Start Qty: 1.00



Cust Item ID:

Required Date: 8/10/10 Req'd Qty: 1.00



Customer:

Reference: RA110015

Run Start



Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Stop



QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Sequence ID/
Work Center IDOperation
DescriptionSet Up/
Run Hours

Tool ID

Tool #

Plan
CodeAccept
QtyReject
QtyReject
NumberInsp.
Stamp

270

QC21 - Final Inspection - Work Order Release

0.00



QC

Memo

0.00

Quality Control

10/08/11
mf
0-8-11

Picklist Print

August 6, 2010 9:24:05 AM

Page 1

Work Order ID: 61098



Parent Item: D212-664-101



Parent Item Name: Crosstube Fwd

Start Date: 8/06/10

Required Date: 8/10/10

Start Qty: 1.00

Required Qty: 1.00

Comments:

IPP Rev:E 04.02.16 Reformat KJ/DS

IPP Rev:F 06-03-29 Remove Coments on Pick List JLM

IPP Rev:G 07-04-30 As per Rev C JLM

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D212-664-101

Manufactured

No

Each

5.0000

1



Crosstube Fwd

Location

Loc Qty

Loc Code

FG

2

57910

1

59531

1

FG103

3

59532

1

60521

1

60522

1

ORIGINAL B/N 44133

PA110015

10/09/8

- DD-664-101 B44133CHG003
- K.T. is complete. new no P/w.
- X-tube can be put back into shoe.

- QCS impact return.

→ needs new labels (destruction)

→ QCS ensure original CHG003 is in Box

→ PPP

- QCS